

WOLF SECTIONAL BEAM

ASSEMBLY INSTRUCTIONS



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
p. 303.442.3212 f. 303.447.9273

© 2016 Schacht Spindle Company, Inc.

03.16

WOLF SECTIONAL BEAM

ASSEMBLY INSTRUCTIONS

PARTS FOR MIGHTY WOLF

- 12 – #8 • 1½" Phillips drive flat head wood screws
- 80 – dowels
- 1 – hammer block
- 4 – sectional beam leaves
- 20 – 40" long cords

PARTS FOR WOLF PUP

- 8 – #8 • 1½" Phillips drive flat head wood screws
- 44 – dowels
- 1 – hammer block
- 4 – sectional beam leaves
- 11 – 40" long cords

1. If there are apron cords and an apron bar installed on the back beam, remove them. These will not be needed once the new Sectional Beam is installed.
2. Place the rounded end of a dowel into the hole in the end of the hammer block (Figure A). Align the flat end of the dowel with the hole in the section and tap the dowel in. If any of the dowels fit loosely, glue them in with a little wood glue.
3. Insert the wood screws into their holes in a sectional beam leaf. The points of the screws should extend out of the hole about 1/2".
4. Place the wood section on one of the flat sides of the octagonal warp beam, butting it up against the aluminum brake drum. Hold the section square and even along the warp beam, and tap gently on the wood screws to make small marks in the beam.

PARTS FOR BABY WOLF

- 8 – #8 • 1½" Phillips drive flat head wood screws
- 60 – dowels
- 1 – hammer block
- 4 – sectional beam leaves
- 14 – 40" long cords

TOOLS

- Hammer or mallet
- Phillips screwdriver
- Drill and 1/8" drill bit

5. Remove the wood section. At each of the marks, drill a 1/8" diameter hole about 3/4" deep. Now screw the wood section to the warp beam. Repeat this process for the other three wood sections.
6. Make loops of the provided cords by tying both ends together with an overhand knot. Insert the cord loops through the holes that have been drilled between the dowels on one of the wood sections and through the knotted end of the cord as illustrated in Figure A. Pull the loop to tighten the cord against the section.

NOTE: Once the sectional beam is installed on an 8 shaft loom, the loom cannot be folded up completely.




FIGURE A

OTHER WEAVING ACCESSORIES



Double Back Beam
(Shown on 8 shaft Baby Wolf)



Wolf Loom Riddle



Wolf Trap



Horizontal Warping Mill